



Installation instructions

1 Cutting and preparing for installation of SmartPS in the façade insulation system



- Set dimensions from power socket on insulation and cut to depth of power socket.
- Apply plaster and insert 300x300 mm reinforcement mesh.
- Cut reinforcement mesh for mounting of power socket.

2 Installation of SmartPS profil i in the facade insulation system



- SmartPS is mounted in the wet plaster.
- Insert the plug into the power socket and apply plaster, reinforcement and finishing plaster. Follow the supplier's instructions.
- SmartPS is now ready for socket installation.